

## DRIVER'S NAVIGATION SUBSYSTEM

Driver's navigation subsystem is comprised of ruggedized computer, fitted with GPS receiver and navigation software.

## **TECHNICAL DATA**

Display: 240 x 320 TFT,OS: Windows Mobile,

• Interface: touch screen, hardware control keys, power status, LED, USB

GPS: L1/SBAS

## **Driver's navigation software**

· position indication on digital map,

- · distance calculation,
- · position of different topographic entities,
- · zoom-in/out options,
- position of allied/foe positions ("blue force tracking" & "red force marking")

